


FIG. 1B









FIG. 1D





I-TLB	DECODED PROPERTY VALUES			PROTECTED	INSTRUCTIONS SENT	COLLECT PROFILE	PROBE FOR TRANSLATED	I/O MEMORY
PROPERTY BITS	ISA 194	ဗ 200		INTERPRETATION	TA.	TRACE- PACKETS?	CODE	REFERENCE EXCEPTIONS
00	TAP	TAP	NO	NATIVE CODE OBSERVING NATIVE RISCY CALLING CONVENTIONS	NATIVE DECODER	NO	NO	FAULT IF SEG.tio
01	TAP	x86	NO	NATIVE CODE OBSERVING x86 CALLING CONVENTIONS	NATIVE DECODER	NO	NO	FAULT IF SEG.tio
10	x86	x86	NO	x86 CODE, UNPROTECTED - TAX! PROFILE COLLECTION ONLY	x86 HW CONVERTER	IF Enabled	NO	TRAP IF PROFILING
11	x86	x86	YES	x86 CODE, PROTECTED - TAX! CODE MAY BE AVAILABLE	x86 HW CONVERTER	IF ENABLED	BASED ON I-TLB PROBE ATTRIBUTES	TRAP IF PROFILING

180,182, 184,186

184,186

FIG. 2A

204							
040	TRANSITION (SOURCE => DEST) ISA & CC PROPERTY VALUES	HANDLER ACTION					
212	00 => 00	NO TRANSITION EXCEPTION					
	00 => 01	VECT_xxx_X86_CC EXCEPTION - HANDLER CONVERTS FROM NATIVE TO x86 CONVENTIONS					
216~	00 => 1x	VECT_xxx_X86_CC EXCEPTION - HANDLER CONVERTS FROM NATIVE x86 CONVENTIONS, SETS UP EXPECTED EMULATOR AND PROFILING STATE					
218~	01 => 00	VECT_xxx_TAP_CC EXCEPTION - HANDLER CONVERTS FROM x86 TO NATIVE CONVENTIONS					
220~	01 => 01	NO TRANSITION EXCEPTION .					
222	01 => 1x	VECT_X86_ISA EXCEPTION [CONDITIONAL BASED ON PCW.X86_ISA_ENABLE FLAG] - SETS UP EXPECTED EMULATOR AND PROFILING STATE					
224~	1x => 00	VECT_xxx_TAP_CC EXCEPTION - HANDLER CONVERTS FROM x86 TO NATIVE CONVENTIONS					
226—	1x => 01	VECT_TAP_ISA EXCEPTION [CONDITIONAL BASED PCW.TAP_ISA_ENABLE FLAG] - NO CONVENTION CONVERSION NECESSARY NO TRANSITION EXCEPTION - [PROFILE COMPLETE POSSIBLE, PROBE POSSIBLE]					
228—	1x => 10						
230~	1x => 11	NO TRANSITION EXCEPTION - [PROFILE COMPLETE POSSIBLE, PROBE NOT POSSIBLE]					

FIG. 2B

	NAME	DESCRIPTION	TYPE
242~	VECT_call_X86_CC	PUSHARGS, RETURN ADDRESS, SET UP x86 STATE	FAULT ON TARGET INSTRUCTION
244~	VECT_jump_X86_CC	SET UP x86 STATE	FAULT ON TARGET INSTRUCTION
246~	VECT_ret_no_fp_X86_CC	RETURN VALUE TO EAX:EDX, SET UP x86 STATE	FAULT ON TARGET INSTRUCTION
248~	VECT_ret_fp_X86_CC	RETURN VALUE TO x86 FP STACK, SET UP x86 STATE	FAULT ON TARGET INSTRUCTION
250~	VECT call TAP_CC	x86 STACK ARGS, RETURN ADDRESS TO REGISTERS	FAULT ON TARGET INSTRUCTION
252~	VECT_jump_TAP_CC	x86 STACK ARGS TO REGISTERS	FAULT ON TARGET INSTRUCTION
254~	VECT_ret_no_fp_TAP_CC	RETURN VALUE TO RV0	FAULT ON TARGET INSTRUCTION
256~	VECT ret any TAP CC	RETURN TYPE UNKNOWN, SETUP RVO AND RVDP	FAULT ON TARGET INSTRUCTION

FIG. 2C




FIG. 3A






FIG. 3B






FIG. 3C






FIG. 3D






FIG. 3E






FIG. 3F




FIG. 3G



```
320
X86-to Tapestry transition exception handler
    // This handler is entered under the following conditions:
    // 1. An x86 caller invokes a native function
    // 2. An x86 function returns to a native caller
    // 3. x86 software returns to or resumes an interrupted native function following
         an external asynchronous interrupt, a processor exception, or a context switch
             -321
    dispatch on the two least-significant bits of the destination address
    case"00"
                     // calling a native subprogram
        // copy linkage and stack frame information and call parameters from the memory
        // stack to the analogous Tapestry registers
                               // set up linkage register — 323
        LR --[SP++]
                               // address of first argument _____324
                                                                                                      322
        AP ~-SP
                                                                            326
                               // allocate return transfer argument area -
        SP -SP - 8
                               // round the stack pointer down to a 0 mod 32 boundary
        SP ~— SP & (-32)
                               // inform callee that caller uses X86 calling conventions -
        XD → 0
                       // resuming an X86 thread suspended during execution of a native routine
     case "01"
        if the redundant copies of the save slot number in EAX and EDX do not match or if
              the redundant copies of the timestamp in EBX:ECX and ESI:EDI do not match {
              // some form of bug or thread corruption has been detected
              goto TAPESTRY_CRASH_SYSTEM( thread-corruption-error-code ) — 372
        save the EBX:ECX timestamp in a 64-bit exception handler temporary register 373
                                                                                                        370
               (this will not be overwritten during restoration of the full native context)
         use save slot number in EAX to locate actual save slot storage ----- 374
         restore full entire native context (includes new values for all x86 registers)
        if save slot's timestamp does not match the saved timestamp { ----376
              // save slot has been reallocated; save slot exhaustion has been detected
              goto TAPESTRY_CRASH_SYSTEM( save-slot-overwritten-error-code ) -
         free the save slot
                         // returning from X86 callee to native caller, result already in registers
     case"10"
                                                     // in case result is 64 bits —
         RV0<63:32> → edx<31:00>
         convert the FP top-of-stack value from 80 bit X86 form to 64-bit form in RVDP
                                                     // restore SP from time of call —
         SP <del>~</del>ESI
                        // returning from X86 callee to native caller, load large result from memory
     case"11"
         RV0..RV3 ← load 32 bytes from [ESI-32] // (guaranteed naturally aligned)
                                                                                                      329
                                                    // restore SP from time of call
         SP -- ESI
                               // reset the two low-order bits to zero -
```



```
Tapestry-to-X86 transition exception handler
   // This handler is entered under the following conditions:
   // 1. a native caller invokes an x86 function
   // 2. a native function returns to an x86 caller
   switch on XD<3:0> { ~
                                 // result type is floating point
   XD RET FP:
       FO/FI ← FINFLATE.de( RVDP) // X86 FP results are 80 bits
                                        // discard RXA, pad, args
       SP → from RXA save
       FPCW → image after FINIT & push // FP stack has 1 entry
       goto EXIT
                                         // store result to @RVA, leave RVA in eax
   XD_RET_WRITEBACK:
                                         // address of result area
        RVA → from RXA save
       copy decode(XD<8:4>) bytes from RV0..RV3 to [RVA]
                                                                                    342
                                         // X86 expects RVA in eax
        eax → RVA
        SP -from RXA save
                                         // discard RXA, pad, args
                                               // FP stack is empty
        FPCW → image after FINIT
        goto EXIT
                                 // result in eax:eda
   XD RET SCALAR:
                                         // in case result is 64 bits
        edx<31:00> <del>-</del> eax<63:32>
                                         // discard RXA, pad, args
        SP ← from RXA save
                                                 // FP stack is empty
        FPCW → image after FINIT
        goto EXIT
   XD_CALL_HIDDEN_TEMP: // allocate 32 byte aligned hidden temp
        esi~-SP
                                         // stack cut back on return
        SP - SP - 32
                                         // allocate max size temp
                                         // RVA consumed later by RR
        RVA~—SP
        LR<1:0> ~~"11"
                                         // flag address for return & reload
        goto CALL COMMON
                                 // remaining XD_CALL_xxx encodings
    default:
                                         // stack cut back on return ~
        esi≺−SP
        LR<1:0> →-"10"
                                         // flag address for return -
CALL COMMON:
        interpret XD to push and/or reposition args -
                                         // push LR as return address
        [--SP] → LR
EXIT:
        setup emulator context and profiling ring buffer pointer
    RFE ____349
                                         // to original target
```

FIG. 31



```
// Control vectors here when a synchronous exception or asynchronous interrupt is to be
   // exported to / manifested in an x86 machine.
// The interrupt is directed to something within the virtual X86, and thus there is a possibility
// that the X86 operating system will context switch. So we need to distinguish two cases:
// either the running process has only X86 state that is relevant to save, or
  there is extended state that must be saved and associated with the current machine context
        (e.g., extended state in a Tapestry library call in behalf of a process managed by X86 OS)
if execution was interrupted in the converter - EPC.ISA == X86 {
        // no dependence on extended/native state possible, hence no need to save any
         goto EM86_Deliver_Interrupt( interrupt-byte )
} else if EPC.Taxi_Active {
        // A Taxi translated version of some X86 code was running. Taxi will rollback to an
        // x86 instruction boundary. Then, if the rollback was induced by an asynchronous external
        // interrupt, Taxi will deliver the appropriate x86 interrupt. Else, the rollback was induced
                                                                                                        353
        // by a synchronous event so Taxi will resume execution in the converter, retriggering the
         // exception but this time with EPC.ISA == X86
         goto TAXi_Rollback( asynchronous-flag, interrupt-byte )
} else if EPC.EM86 {
         // The emulator has been interrupted. The emulator is coded to allow for such
         // conditions and permits re-entry during long running routines (e.g. far call through a gate)
         // to deliver external interrupts
         goto EM86_Deliver_Interrupt( interrupt-byte )
} else {
         // This is the most difficult case - the machine was executing native Tapestry code on
         // behalf of an X86 thread. The X86 operating system may context switch. We must save
         // all native state and be able to locate it again when the x86 thread is resumed.
         allocate a free save slot, if unavailable free the save slot with oldest timestamp and try again
         save the entire native state (both the X86 and the extended state)
                                                                                         362
         save the X86 EIP in the save slot
         overwrite the two low-order bits of EPC with "01" (will become X86 interrupt EIP)
         store the 64-bit timestamp in the save slot, in the X86 EBX:ECX register pair (and,
                  for further security, store a redundant copy in the X86 ESI EDI register pair)
         store the a number of the allocated save slot in the X86 EAX register (and, again for
                  further security, store a redundant copy in the X86 EDX register)
         goto EM86_Deliver_Interrupt( interrupt-byte ) -
 }
```

interrupt/exception handler of Tapestry operating system:

FIG. 3J



```
typedef struct {
                                         // pointer to next-most-recently-allocated save slot
   save_slot_t *
                         newer,
                                         // pointer to next-older save slot
                        older;
   save_slot_t *
                                         // saved exception PC/IP
   unsigned int64
                         epc;
                                         // saved exception PCW (program control word)
   unsigned int64
                         pcw;
                                         // save the 63 writeable general registers
                         registers[63];
   unsigned int64
                                          // other words of Tapestry context
                                          // timestamp to detect buffer overrun
   timestamp_t
                         timestamp;
                         save_slot_ID;
                                         // ID number of the save slot >
   int
                                                  // full / empty flag
                         save_slot_is_full;
   boolean
} save_slot_t;
                                                  // pointer to the head of the queue ~
                         save_slot_head;
save_slot_t *
save_slot_t *
                         save_slot_tail;
```

system initialization reserve several pages of unpaged memory for save slots

FIG. 3K




FIG. 3L






FIG. 3M






FIG. 3N







FIG. 30









FIG. 4A





		0011	nor		ROFILEA EVENT	•	INITIAT PACKE	Ī E	BEABLE VENT
		SOU	KUE	414	410)	418) (612
			CODE 402	EVENT	REUSE EVENT CODE				PROBE EVENT BIT- ITLB PROBE ATTRIBUTE OR EMULATOR PROBE
		\perp		TO THE PROPERTY OF THE PERSON AND CONTROLLED VALUE			110		DELICE EVENT CODE
	412 		0.0000	DEFAULT (x86 TRANSPARENT) EVENT, REUSE ALL CONVERTER VALUES	YES		NO		REUSE EVENT CODE REUSE EVENT CODE
41			0.0001	SIMPLE x86 INSTRUCTION COMPLETION (REUSE EVENT CODE)	YES		NO		
["			0.0010	PROBE EXCEPTION FAILED	YES		NO		REUSE EVENT CODE
			0.0011	PROBE EXCEPTION FAILED, RELOAD PROBE TIMER	YES	110	NO	NO	REUSE EVENT CODE
			0.0100	FLUSH EVENT	NO	NO VEO	NO NO	NO	•
			0.0101	SEQUENTIAL; EXECUTION ENVIRONMENT CHANGED - FORCE EVENT	NO	YES	NO VEO	NO.	•
	rfe		0.0110	FAR RET	NO	YES	YES	NO	•
110	ntext_\		0.0111	IRET	NO NO	YES	NO VEO	NO YES	· ·
M	POINT VTRY)	IJ	0.1000	FAR CALL	NO	YES	YES	YES	FAR CALL
"	iini)		0.1001	FAR JMP	NO	YES	YES	NO	•
		ļ	0.1010	SPECIAL; EMULATOR EXECUTION, SUPPLY EXTRA INSTRUCTION DATA	NO	YES	NO	NO	·
			0.1011	ABORT PROFILE COLLECTION	NO	NO NO	NO	NO	FHIR 1703 D3005
			0.1100	x86 SYNCHRONOUS/ ASYNCHRONOUS INTERRUPT W/PROBE (GRP 0)	NO	YES	YES	YES	EMULATOR PROBE
			0.1101	x86 SYNCHRONOUS/ASYNCHRONOUS INTERRUPT (GRP 0)	NO	YES	YES	NO.	· FULL TOD DDODE
			0.1110	x86 SYNCHRONOUS/ASYNCHRONOUS INTERRUPT W/PROBE (GRP 1)	NO_	YES	YES	YES	EMULATOR PROBE
l			0.1111	x86 SYNCHRONOUS/ASYNCHRONOUS INTERRUPT (GRP 1)	NO	YES	YES	NO.	•
ſ	CONVERTER (NEAR_ EDGE ENTRY)	\vdash	1.0000	IP-RELATIVE JNZ FORWARD (OPCODE: 75, OF 85)	NO	YES	YES	NO	•
			1.0001	IP-RELATIVE JNZ BACKWARD (OPCODE: 75, OF 85)	NO	YES	YES	YES	JNZ
			1.0010	IP-RELATIVE CONDITIONAL JUMP FORWARD - (JCC, JCXZ, LOOP)	NO	YES	YES	NO	·
i			1.0011	IP-RELATIVE CONDITIONAL JUMP BACKWARD - (JCC, JCXZ, LOOP)	NO	YES	YES	YES	COND JUMP
			1.0100	IP-RELATIVE, NEAR JMP FORWARD (OPCODE: E9, EB)	NO	YES	YES	NO	
			1.0101	IP-RELATIVE, NEAR JMP BACKWARD (OPCODE: E9, EB)	NO	YES	YES	YES	NEAR JUMP
			1.0110	RET/RET IMM16 (OPCODE C3, C2 /W)	NO	YES	YES	NO	·
- 1		1	1.0111	IP-RELATIVE, NEAR CALL (OPCODE: E8)	NO	YES	YES	YES	NEAR CALL
404			1.1000	REPE/REPNE CMPS/SCAS (OPCODE: A6, A7, AE, AF)	NO	YES	NO	NO.	· ·
			1.1001	REP MOVS/STOS/LDOS (OPCODE: A4, A5, AA, AB, AC, AD)	NO	YES	NO	NO.	
			1.1010	INDIRECT NEAR JMP (OPCODE: FF /4)	NO	YES	YES	NO	•
			1.1011	INDIRECT NEAR CALL (OPCODE: FF 12)	NO	YES	YES	YES	NEAR CALL
			1.1100	LOAD FROM I/O MEMORY (TLB ASI !=0) (NOT USED IN T1)	NO	YES	NO	NO	·
			1.1101	AVAILABLE FOR EXPANSION	NO.	NO	NO	NO	· · · · ·
İ			1.1110	DEFAULT CONVERTER EVENT; SEQUENTIAL 406	NO	NO	NO.	NO	•
l			1.1111	NEW PAGE (INSTRUCTION ENDS ON LAST BYTE OF A PAGE FRAME OR STRADDLES ACROSS A PAGE FRAME BOUNDARY) 408	NO	YES	NO	NO	
				EIG AR					

FIG. 4B














492 1 1 1 1 1 1 1 1 8 7 6 5 4

Profile_Timer


2 0

630

Probe Timer


FIG. 41





ap EVENT: PA — 0










FIG. 6A



EVENT CODE FROM RFE RESTARTING CONVERTER OR MAPPING OF CONVERTER'S x86 OPCODE

RFE OR PREVIOUS CONVERTER CYCLE




FIG. 6B

